

**1 TO 4  
CAN PLAY**

# **INSTRUCTIONS**

**FOR  
AMUSEMENT  
ONLY**

- ★ INSERT COIN AND WAIT FOR MACHINE TO RESET BEFORE INSERTING COIN FOR NEXT PLAYER.
- ★ **1 REPLAY** FOR EITHER TOP ROLLOVER BUTTON MADE WHEN LIT FOR SPECIAL.
- ★ 2 TOP ROLLOVER BUTTONS LITE ALTERNATELY TO SCORE SPECIAL WHEN BONUS REACHES 19,000.
- ★ SIDE SAUCERS LITE ALTERNATELY TO SCORE EXTRA BALL WHEN BONUS REACHES 11,000.
- ★ BOTTOM LANES LITE ALTERNATELY TO SCORE 5,000 WHEN BONUS REACHES 11,000.
- ★ **1 BONUS** ADVANCE FOR EACH FLIP.
- ★ MUSHROOM BUMPERS LITE TO RESET FLIPS WHEN ALL FLIPS ARE MADE.
- ★ HITTING MUSHROOM BUMPERS WHEN LIT RESETS FLIPS AND ADVANCES BONUS 4 STEPS.
- ★ **DOUBLE BONUS** ON 3RD AND 5TH BALL.
- ★ **1 REPLAY** FOR EACH PLAYER MATCHING LAST TWO NUMBERS ON SCORE REELS WITH NUMBER WHICH LITES ON BACKGLASS AT END OF GAME.