

# **GENERAL INSTRUCTIONS FOR TARGET GALLERY**

## **1. INSTALLATION:**

- Fasten the 4 legs to cabinet with furnished bolts.
- Install the back-box on the cabinet with furnished bolts and attach all disconnect jacks.
- Put the furnished 13/16" diameter steel balls into opening of ball return trough which is accessible above the cash box.
- Level the game and adjust the front tilt switch.
- Plug the line cord into A.C. only, 60 cycles, 115 volts; the power is controlled by a toggle switch located under the front part of the game.

## **2. VOLTAGE CONTROL: In low voltage areas (105 volts or less) an additional boost in the output voltage of the transformer can be obtained by inserting the transformer voltage control fuse into the "LOW LINE" fuse position.**













## **3. SCORE REPLAY CONTROL JACK is located on the 100 score drum unit. It is also used as a control for the "PLAY AGAIN" feature on the non-replay model.**

## **4. TO SERVICE TARGET PANEL:**

- Disconnect the small jack on the back door.
- Remove top two screws holding canopy to cabinet.
- Trip all animals and slide target panel out.

*Midway Mfg. Co.*

5c – 20 BALLS per game	10c – 20 BALLS per game												
<div><div></div><ul style="list-style-type: none"><li>• Rabbits and Squirrels score as indicated. Hitting both targets with one ball will score both.</li><li>• Bat ball EARLY to hit targets at left side.</li><li>• Bat ball LATE to hit targets at right side.</li></ul><div></div></div>	<div><div></div><ul style="list-style-type: none"><li>• Rabbits and Squirrels score as indicated. Hitting both targets with one ball will score both.</li><li>• Bat ball EARLY to hit targets at left side.</li><li>• Bat ball LATE to hit targets at right side.</li></ul><div></div></div>												
<div><div></div><div><div><div>REPLAYS</div><table><tr><td>2000 – 1 replay</td><td>3300 – 4 replays</td></tr><tr><td>2300 – 2 replays</td><td>3600 – 5 replays</td></tr><tr><td>2600 – 3 replays</td><td>4300 – 6 replays</td></tr></table><p>LOWER pockets score 1 replay when SPECIAL is lit.</p><p>— Press Coin Reject Button —</p></div><div>TG-24</div></div></div>	2000 – 1 replay	3300 – 4 replays	2300 – 2 replays	3600 – 5 replays	2600 – 3 replays	4300 – 6 replays	<div><div></div><div><div><div>REPLAYS</div><table><tr><td>1900 – 1 replay</td><td>3200 – 4 replays</td></tr><tr><td>2000 – 2 replays</td><td>3600 – 5 replays</td></tr><tr><td>2600 – 3 replays</td><td>4200 – 6 replays</td></tr></table><p>LOWER pockets score 1 replay when SPECIAL is lit.</p><p>— Press Coin Reject Button —</p></div><div>TG-30</div></div></div>	1900 – 1 replay	3200 – 4 replays	2000 – 2 replays	3600 – 5 replays	2600 – 3 replays	4200 – 6 replays
2000 – 1 replay	3300 – 4 replays												
2300 – 2 replays	3600 – 5 replays												
2600 – 3 replays	4300 – 6 replays												
1900 – 1 replay	3200 – 4 replays												
2000 – 2 replays	3600 – 5 replays												
2600 – 3 replays	4200 – 6 replays												
<div><div></div><div><div><div>REPLAYS</div><table><tr><td>2100 – 1 replay</td><td>3300 – 4 replays</td></tr><tr><td>2300 – 2 replays</td><td>3600 – 5 replays</td></tr><tr><td>2600 – 3 replays</td><td>4300 – 6 replays</td></tr></table><p>LOWER pockets score 1 replay when SPECIAL is lit.</p><p>— Press Coin Reject Button —</p></div><div>TG-34</div></div></div>	2100 – 1 replay	3300 – 4 replays	2300 – 2 replays	3600 – 5 replays	2600 – 3 replays	4300 – 6 replays	<div><div></div><div><div><div>REPLAYS</div><table><tr><td>_____ – 1 replay</td><td>_____ – 4 replays</td></tr><tr><td>_____ – 2 replays</td><td>_____ – 5 replays</td></tr><tr><td>_____ – 3 replays</td><td>_____ – 6 replays</td></tr></table><p>LOWER pockets score 1 replay when SPECIAL is lit.</p><p>— Press Coin Reject Button —</p></div><div>TG-40</div></div></div>	_____ – 1 replay	_____ – 4 replays	_____ – 2 replays	_____ – 5 replays	_____ – 3 replays	_____ – 6 replays
2100 – 1 replay	3300 – 4 replays												
2300 – 2 replays	3600 – 5 replays												
2600 – 3 replays	4300 – 6 replays												
_____ – 1 replay	_____ – 4 replays												
_____ – 2 replays	_____ – 5 replays												
_____ – 3 replays	_____ – 6 replays												

 <p><b>PLAY AGAIN IF SCORE OF 1700 IS MADE</b></p> <p><i>— Press Coin Reject Button —</i></p> 	 <p><b>PLAY AGAIN IF SCORE OF 1800 IS MADE</b></p> <p><i>— Press Coin Reject Button —</i></p> 
 <p><b>PLAY AGAIN IF SCORE OF 1900 IS MADE</b></p> <p><i>— Press Coin Reject Button —</i></p> 	 <p><b>PLAY AGAIN IF SCORE OF 2000 IS MADE</b></p> <p><i>— Press Coin Reject Button —</i></p> 
 <p><b>PLAY AGAIN IF SCORE OF 2100 IS MADE</b></p> <p><i>— Press Coin Reject Button —</i></p> 	 <p><b>PLAY AGAIN IF SCORE OF _____ IS MADE</b></p> <p><i>— Press Coin Reject Button —</i></p> 

Fonts used: Futura BdCn BT, Futura Hv BT, Futura-Thin, Futura Std Medium, BrushScriptOpti  
Card size: 213x200mm, 57x82mm, 29x82mm

**Card status:**

General Instructions card confirmed.  
5c instructions card confirmed.  
10c instructions card confirmed.  
TG-24 score card confirmed.  
TG-30 score card confirmed.  
TG-34 score card confirmed.  
TG-40 score card confirmed.  
Play Again at 1700 card confirmed.  
Play Again at 1800 card confirmed.  
Play Again at 1900 card confirmed.  
Play Again at 2000 card confirmed.  
Play Again at 2100 card confirmed.  
Play Again at blank card confirmed.

If you have any more information, please send me an image.

Enjoy and have fun,  
Peter

[www.inkochnito.nl](http://www.inkochnito.nl)

If you like my work, please send me a donation via PayPal.